



## CHANGING BATTERIES:

Batteries must be replaced by an adult.  
Insert batteries with the polarity oriented as indicated.



*Requires 3 LR41 batteries (1.5V)  
- included*

*Press down  
to turn on or off the light*



## READ THE INSTRUCTIONS CAREFULLY BEFORE USING THE PRODUCT

- 1) Non rechargeable batteries should not be charged.
- 2) Do not mix different types of batteries.
- 3) Do not mix new and used batteries.
- 4) Only the recommended type of batteries should be used.
- 5) Batteries should be inserted and oriented with the correct polarity.
- 6) Exhausted batteries should be removed from the product.
- 7) The battery terminals must not be short-circuited.
- 8) Batteries should be disposed in an appropriate place.
- 9) Remove batteries when not in use or discharged.

*Information to be kept for future reference.*