

ASSEMBLY INSTRUCTIONS

JAWA™ SIXTH SCALE FIGURE SET

ATTENTION: PLEASE USE CAUTION DURING ASSEMBLY

FOR FURTHER ASSISTANCE:

CALL US (WITHIN U.S.): 1-855-SIDESHOW


CALL US (OUTSIDE U.S.): 1-805-214-2157



READ THE INSTRUCTIONS CAREFULLY BEFORE USING THE PRODUCT

Product uses two (2) LR41 batteries (located on backside of head)

1. Non rechargeable batteries should not be charged.
2. Do not mix different types of batteries.
3. Do not mix new and used batteries.
4. Only the recommended type of batteries should be used.
5. Batteries should be inserted and oriented with the correct polarity.
6. Exhausted batteries should be removed from the product.
7. The battery terminals must not be short-circuited.
8. Batteries should be disposed in an appropriate place.
9. Remove batteries when not in use or discharged.



To enable the light-up eyes feature, turn switch (located on backside of head) to the right 'ON' position. To replace batteries, unscrew the cover.



OPTION 1: Start with curved side of hood



Place hood on figure bringing the hood's flaps to the front of the figure then overlap/cross flaps over the mouth area and wrap around to the back.



Finished view (front and back)



OPTION 2: Start with straight side of hood



Place hood on figure bringing the hood's flaps to the front of the figure then overlap/cross flaps over neck areas and wrap around to the back.



Finished view (front and back)



SIDESHOW

For more information visit: SIDESHOW.COM/Instructions