## **ASSEMBLY INSTRUCTIONS**

## BB-8 PREMIUM FORMAT™ FIGURE

## **ATTENTION:** PLEASE USE CAUTION DURING ASSEMBLY

CALL US (WITHIN U.S.): 1-855-SIDESHOW

FOR FURTHER ASSISTANCE:

CALL US (OUTSIDE U.S.): 1-805-214-2157





DOME LED light up components: Locate the battery pack under BB-8's dome and pull out connection plastic tab (Three LR44 batteries have been included). Insert antennas as shown. Locate the LED TOUCH sensor as shown to turn on the light up feature.




Slide BB-8's sphere onto base key. Locate the LED TOUCH sensor as shown to turn on the light up feature. BB-8's sphere has a magnetized track on top where the dome will be placed. Place BB-8's dome gently on the magnetized area.

**SIDESHOW** 

EXCLUSIVE: Use BB-8's magnetized dome to access exclusive hinged panel and insert torch arm.



BODY LED light up components: Locate the battery pack under BB-8's sphere and use a phillips screwdriver to access it. Three AAA batteries have been included for you to install. Locate the slot that is used to place BB-8 onto it's base.



## For more information visit: SIDESHOW.COM/Instructions