

CONTENT P.2 A. LED LIGHT-UP FUNCTIONS | LED发光功能 A. LED LIGHT-UP FUNCTIONS | LED发光功能 B. DIORAMA FIGURE STAND | 情景地台 P. 4 C. DAMAGED ULTRON MARKI | 选损奥创MKI P.5 D. INTERCHANGEABLE HEADS | 可替換头部 E. INTERCHANGEABLE CHEST ARMOR | 可替换胸甲 P.6 F. INTERCHANGEABLE FOREARM ARMOR | 可替换前臂装甲零件 P.7 G. INTERCHANGEABLE REPULSOR PALMS AND GAUNTLETS 可替换手部和护腕 H. ARM MOVEMENT | 手部活动 I. EXTENDED SHOULDER MOVEMENT | 肩膀活动 J. FULLY DEPLOYED AIR FLAPS | 风门系统 P.8 K. WAIST MOVEMENT | 腰部活动

L. FOOT MOVEMENT | 脚部活动

M. LEG MOVEMENT | 配部活动

CAUTION | 注意

CAUTION | 注意

WARNING | 警告

IRON MAN

HOT TOYS PRESENTS MOVIE MASTERPIECE SERIES-DIECAST

- PRODUCERS HOWARD CHAN & JC. HONG
- DESIGNERS JASON WOO & TERRY CHENG
- SCULPTORS KOJUN & LEE SO YOUNG
- PAINTER JC. HONG
- ART DIRECTOR JC. HONG
- DESIGNERS JASON WOO & ALEX TSANG CONTROLLERS JC. HONG, JASON WOO & LOK HO
- SUPERVISORS TS WONG & WING CHOW
- DESIGNERS DIXON CHAN & MONSTER JR.
- PHOTOGRAPHY RAY MAK
- CONTROLLERS JASON WOO, TERRY CHENG & FAI LUI


A. LED LIGHT-UP FUNCTIONS | LED 发光功能



Take off the mask as shown. 把面罩拆下。




Slightly widen the top of the 稍微拉开头盔的顶部,然后把它拆下。




 Unscrew and open the battery box to put in new batteries. Three batteries (AG1/LR621, 1.5V) are included. 松开螺絲打开电池箱盖然后放入电池。盒内包含了3颗电池(AG1/LR621, 1.5V)。 Activate the light-up function by turning the on/off switch. 利用开关键启动发光功能。



Complete as shown. 完成。



Unscrew and open the battery box to put in new batteries. 松开螺絲打开电池箱盖然后放入电池。



• Three batteries (AG1/LR621, 1.5V) are included. 盒内包含了3颗电池 (AG1/LR621, 1.5V) 。 Activate the light-up function by turning the on/off switch. 利用开关键启动发光功能。

weight.

由于人偶的重量,不要配合其他款式的地台使用。



Complete as shown. 完成。

B. DIORAMA FIGURE STAND | 情景地台

完成。

P.3

P.2




• Three batteries (AG1/LR621, 1.5V) are included. 盒内包含了3颗电池 (AG1/LR621, 1.5V) 。 Activate the light-up function by turning the on/off switch. 利用开关键启动发光功能。





 Attach the metal pillar and the figure holding clip to the base. 把金属支架安装在地台上。 · Complete as shown.



Don't use other figure stands with this figure; A screwdriver will come with the otherwise, the stand will be damaged due to figure's figure set. 盒内包含了一把专用螺丝刀。

C. DAMAGED ULTRON MARK I | 战损奥创MK I

Unscrew and open the battery box to put in new batteries.

松开螺絲打开电池箱盖然后放入电池。




Damaged Ultron Mark I. 战损奥创MKI。




The damaged Ultron Mark I can be placed on the figure stand. Complete as shown. 战损奥创MKI可放在地台上。







The indicated heads are attachable to the figure. Battle Place the magnetic mask onto Tony Stark's forehead as shown. damaged Mark XLIII helmet Only available in Special Edition. 把带有磁石零件的面罩根据图示配戴。 人偶可以使用这三款头雕。 (MK XLIII战损头盔是特别版独有配件)




颈部零件可以拆下。




The head and arm are detachable on the damaged Ultron Mark I. 战损奥创MKI的头和手可以拆下。



The head can turn within 180°. 头部能180°转动。





The arm can turn within 90°.



Detach the chest armor. 胸甲可以拆下。


P.5






注意:肩膀装甲零件不能拆下。


F. INTERCHANGEABLE FOREARM ARMOR | 可替换前臂装甲零件





Take off the palm and gauntlet. 把手和护腕拆下。



· Detach or attach the forearm armor parts as shown. 按图示安装或拆下前臂装甲。








forearm armor. 发射火箭炮装甲只能安装在右手。

- Only the normal forearm armor can be attached to the left arm 左手只能安装正常装甲。

P.6

G. INTERCHANGEABLE REPULSOR PALMS AND GAUNTLETS | 可替换手部和护腕



The indicated gauntlets and palms can be attached onto the figure. 图示的装甲零件和手掌可以相应地安装。



The arm can be raised within 90° 前臂可以向上举起90°。




Slightly pull out the shoulder.

把肩膀稍微拉出。

P.7




Now the shoulder can be moved forward within 30° The air flaps can move upward within 90°. 现在肩膀能向前移动30°。



K. WAIST MOVEMENT | 腰部活动



Extend the waist by pulling up the upper body. It can now be moved to the preferred position within 45°.



positioning if needed.

BACK | 背面


CAUTION | 注意




Be careful when moving the shoulder backward; otherwise, the armor parts on the shoulder blade and bicep may collide and lead to paint fading. 肩膀向后移动时要注意,否则装甲有机会磨擦引致掉漆。



Be careful when bending or positioning the feet; otherwise, the armor parts may collide and lead to paint fading. 移动脚部时要注意,否则装甲有机会磨擦引致掉漆。






position.

M. LEG MOVEMENT | 腿部活动

腰部位置能伸展,移动角度可增加至45°。




Be careful of sharp edges on the armor.

Don't mix old and new batteries.

小心人偶锋利的位置。

WARNING

Flaps can be pushed up for easier positioning of the legs. 图示的装甲可以向上移动方便 腿部活动。







The legs can now be moved to preferred position within 90°. 双腿现可以向上举起90°。

P.8

P.10



The figure is heavy in weight. Please handle with care. 人偶重量不轻, 请小心。





- . 电力耗尽之电池应取出。 . 电源两端不可短路。
- · 激光輻射, 勿直視光束。
- Please change the battery and observe the status of battery regularly to avoid leakage which may cause damage to the product and its electricity system. Note: The above situations are not included in maintenance nor replacement.


Don't mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

· Batteries installation and parts assembly should be done by an adult.


. Don't look at the LED light directly; it may be harmful to eyes.

- . 电池以正确之极性置入。
- · 非充电电池不能充电。

- Complete as shown. 完成。




手可以90°转动。



P.4


NORMAL ARMOR 正常装甲




The right arm can be interchanged with normal or missile launching

FOOT MOVEMENT 脚部活动

Extend the foot by pulling it down slightly for 脚部能向下稍微拉出方便活动。



Don't excessively rotate the body or extend the waist; otherwise, the armor parts may collide and lead to paint fading 不要过度扭曲或伸展腰部,否则装甲有机会磨擦引致掉漆。



建议先把脚部拉下才移动至想要的姿势。



