

ASSEMBLY INSTRUCTIONS

MMDCMT-02DX Museum Masterline Dark Nights: Metal (Comics) Batman Versus Joker Dragon Deluxe Version



MUSEUM MASTERLINE BATMAN™



REMOVAL INSTRUCTIONS



▲ NOTICE

This product contains a lot of small fragile parts, which may dislocate or move during shipment. Should you notice this during assembly, we advise to carefully heat up the specific element with a hairdryer (on low setting) for about 45-60 seconds from a 10 cm distance. When warm, carefully adjust the part to the correct position, and let it cool down.

本製品には輸送中に変形する可能性がある、小さな部品が多数含まれています。組み立て中にそのような部品があった場合には、ドライヤーを当てて暖めてください。熱い過ぎず、部品が柔らかくなる程度で、低温で10cm程度の距離から45-60秒ほど当ててください。暖かくなったら、部品の位置を正しく調整し、元の形に戻すまでお持ちください。

由于本品包含许多易碎的小零件，在运输过程中可能会出现一定的移位情况。如您发现零件在运输过程中出现移位，我们建议您用吹风机以低档位小心加热该零件约45-60秒，吹风机与零件保持10厘米左右的距离为宜。如果零件移位，请小心地将零件调整至正确的位置并等待其自然冷却。

ASSEMBLY INSTRUCTIONS

MMDCMT-02DX Museum Masterline Dark Nights: Metal (Comics) Batman Versus Joker Dragon Deluxe Version



LED Light ON/OFF Switch

There are two types of LED light: press once to turn on light; press twice to turn on the fade light mode; then press it again to turn off the LED light.

LEDライトはスイッチを1回押すと点灯し、2回押すと点滅します。ライトを消す際は、さらにもう一度押してください。LEDは2段階。長押しで点灯、短押しで点滅、再度短押しで消灯。最後に一度長押し。