


ASSEMBLY INSTRUCTIONS

MMW3-01 Museum Masterline The Witcher 3: Wild Hunt Geralt of Rivia



REMOVAL INSTRUCTIONS



NOTICE


This product contains a lot of small fragile parts, which may dislocate or move during shipment. Should you notice this during assembly, we advise to carefully heat up the specific element with a hairdryer (on low setting) for about 45-60 seconds from a 10 cm distance. When warm, carefully adjust the part to the correct position, and let it cool down.

本製品には輸送中に変形する可能性がある、小さな部品が多数含まれています。組み立て中にそうした部品があった場合には、ドライヤーを当てて復元してください。熱し過ぎは破損の原因になりますので、低温で10cm程度の距離から45〜60秒ほど当ててをお勧めします。部品が温まったら少しずつ成形し、元の形になったら冷めるまでお待ちください。

由于本商品含有许多较为脆弱的细小配件，在运输过程中可能出现一定的移位情况。如您再组装过程中发现以上情况发生，我们建议您以吹风机的低档模式小心加热移位的配件大约45-60秒，吹风机与配件保持10厘米左右的距离为佳。如果您感觉配件已经被加热充分，请小心的将其移至正确的位置并等待其自然冷却。



<https://www.primestudio.com/>  
<https://www.facebook.com/Prime1Studio>  
<https://www.instagram.com/Prime1Studio>  
<https://twitter.com/Prime1Studio>



CD PROJEKT®. The Witcher® are registered trademarks of CD PROJEKT Capital Group.  
The Witcher game © CD PROJEKT S.A. Developed by CD PROJEKT S.A. All rights reserved.  
The Witcher game is set in the universe created by Andrzej Sapkowski in his series of books.  
All other copyrights and trademarks are the property of their respective owners.